


	INTAKE	EXHAUST
ADVERTISED DURATION	276°	276°
ACTUAL CAM LIFT (in/mm)	.436" / 11.07mm	.436" / 11.07mm
ROCKER ARM RATIO	1.73:1	1.73:1
CENTERLINE	107°	113°
LOBE SEPERATION	110°	
DURATION AT 0.050" CAM	200°	200°
DURATION AT 0.050" VALVE	216°	216°
VALVE CLEARANCE	.000" / 0mm HYDRAULIC	.000" / 0mm HYDRAULIC
RECOMMENDED SPRING KIT	BC0100 or BC0120	

		OPEN	CLOSES
CAMSHAFT TIMING AT 0.050" VALVE LIFT	INTAKE	1° BTDC	35° ABDC
	EXHAUST	41° BBDC	5° BTDC



NOTES

BC does not recommend using synthetic oil during break-in or operation. Follow OEM manufacturer's torque sequence and specifications. Use liberal amount of aftermarket engine assembly lube during installation. Check follower or bucket surfaces for abnormal wear and/or scuffing. On initial start-up and break-in run engine at 1500-2500 rpm for 20 minutes. **Camshafts damaged by improper installation, excessive spring pressure or retainers contacting valve guides or seals are void from warranty. Not legal for sale or use on emission controlled motor vehicles.**